



'Attach An Oil' Diffuser

Directions

“Quite simply THE BEST. Incredibly well engineered & built from the best components.”

*Steven C. Fischer, PhD, CNC, PC
Licensed Psychologist
Certified Nutritional Consultant*

The Most Advanced Diffusion Technology Built:

- Innovative, compact, all-in-one design
- Built-in timers and power control
- State-of-the-art cold diffusion technology
- Patented "Quick Change" system (uses no water)
- Allows oil changes without mixing or spilling
- Powerful, effective, and easy to use
- Directional control spout and sound reducer
- Revolutionary nebulizer technology
- Atomizes micro-fine oil vapor approx. 1-3 microns
- Non-slip grip for easy pick up
- 15ml or 30ml bottle capacity
- Adjustable at micro intervals for perfect emitting
- Extended operation and low maintenance intervals

- Powerful pump delivers up to 5 pounds of pressure
- Strong molded body for increased life & durability
- Compact one piece design for space efficiency
- Tip resistant base for added stability
- Built in filter to clean the air and keep dust out

Directions - How To Attach A Bottle Of Oil:

Changing essential oils has never been easier than with the 'Attach An Oil' Diffuser. It only takes a few seconds to change oil any time.

1. Open your 15 ml or 30 ml bottle of essential oil and set the cap aside.
2. Remove the plastic emitter insert from your open bottle of oil and set it aside.
3. Screw the wide open mouth of your oil bottle onto the atomizer attachment, ensuring the bottle fits snugly. Note: Oil may leak if the bottle is not fully secured to the atomizer.
4. Tilt the atomizer, then insert into the diffuser socket (the pump housing).
5. Push the atomizer into the diffuser socket, then rotate the atomizer assembly clock-wise until it's locked into the diffuser, bringing the diffuser to the upright position.
6. Now adjust the control settings as desired & enjoy.

Directions - How To Adjust The Controls:

RUN TIME 1-20 MINUTES: Set the "RUN TIME" control knob for however long you desire your diffuser to RUN before the "REST" cycle (1 to 20 Minutes). The green LED light is illuminated during the "RUN" cycle.

REST TIME 1-20 MINUTES: Set the "REST TIME" control knob for however long you desire your diffuser to REST before the "RUN" cycle (1 to 20



Use with Essanté Organics
USDA Organic, Therapeutic Grade,
Undiluted Essential Oils

Essential Oils;
The First Medicine Known To Man



Minutes). The amber LED light is illuminated during the "REST" cycle.

OUTPUT PRESSURE: Set the "OUTPUT PRESSURE" control knob to desired volume (desired amount of oil emitted). Click the ON/OFF switch and then rotate the "OUTPUT PRESSURE" control knob to increase volume (increase amount of oil emitted).

RUN TIME / REST TIME: The "RUN TIME" and "REST TIME" will alternate indefinitely until the unit is turned off.

Safety Instructions:

- Read and follow all cautions and instructions
- For indoor use only
- Do not operate with wet hands
- Keep the unit in an upright position
- Keep out of the reach of children and pets
- Unplug from wall outlet when not in use
- To be serviced by qualified technician only
- Do not use near water, shower, sink, tub, pool, etc.
- Use in accordance with local laws & regulations
- Do not use with any harmful substances
- Never set on a surface that can be damaged by essential oils

Avoid Pump Damage:

Always keep your diffuser in an upright position when an essential oil bottle is attached to it. The air pump can be damaged if the unit is rotated where oil can enter the air pump.

Remove atomizer when transporting the unit or changing oils.