



Essanté
ORGANICS®

CLASSIC
Ultrasonic Nebulizer™
Perfect for essential oils and fragrances

IF SERVICE IS NEEDED:
COMPLETE, DETACH & SUBMIT TO CORPORATE
WITH DATED SALES RECEIPT & THE INOPERABLE NEBULIZER

LIMITED 90 DAY WARRANTY

This product is warranted free from defects in workmanship and in materials for a period of 90 days from date of purchase. Damages caused by misuse, accident, attachment of unauthorized parts, alterations, or any other condition beyond our control are not covered. We shall not be responsible for any type of incidental, consequential or unrelated damages. All implied warranties are limited to 90 days from original purchase date. To obtain warranty service, please submit the unit, your original dated sales receipt & this completed form below. Contact the retailer where the diffuser/nebulizer was purchased. We are confident you will enjoy long-term satisfaction, pleasant effects and benefits.

NAME _____

ADDRESS _____

PHONE _____ EMAIL _____

PURCHASE DATE _____ LOCATION _____

PROBLEM WITH UNIT (BE SPECIFIC) _____



Instruction
Manual

WWW.ESSANTEORGANICS.COM

11001 N 24th Ave., #612 Phoenix, AZ 85029 (602) 595-7560

Our patented, award winning, cool vapor technology allows essential oil molecules to stay suspended in the air longer, creating greater therapeutic benefit.



SUPERIOR THERAPEUTIC BENEFITS:

Ultrasonic diffusers create a fine mist by utilizing electronic frequencies to cause a small disk, under the surface of the liquid (water), to vibrate at a very fast rate. These ultrasonic vibrations break the essential oil into tiny micro particles, dispersing the oil in a fine, highly absorbable mist. The lungs receive a far greater therapeutic benefit, as does the entire body, mind, & spirit, because tiny particles are more easily absorbed.

While the transformation of water into vapor normally requires great heat, the ultrasonic diffuser (nebulizer) transforms liquid into vapor through an adiabatic process, meaning a change in the state of the liquid is accomplished *without any kind of heat* being used.

Cool mist allows essential oils to stay in their proper, most potent, therapeutic state.

Products not intended to diagnose, treat, cure or prevent disease.

"This is the best diffuser I've used. I have one in each bedroom. It's so quiet, it purifies the air & I notice a significant difference in my family's health & mood. It's even a night light for our toddler."
~ John L.






Why? Because Mother Nature Knows What's Best...

ESSANTÉ ORGANICS

ESSENTIAL OILS
*THE FIRST MEDICINE
KNOWN TO MAN*

OPERATING INSTRUCTIONS:

1. Remove the clear, 2 part, plastic dome lid (cover).
2. Fill the white water tank with pure water up to the white fill line.
3. Add 3-8 drops of essential oil in water.
4. Replace clear lid/cover & turn the small clear emitter to your preferred angle.
5. **With dry hands**, plug the small end of the black power supply into the back of the unit. Plug the large square adaptor end of power cord into a wall outlet.
6. Press the power button (on/off button).
7. Press the timer button (press once for minimal time. Press 5 times for maximum time. 1-5 green lights will appear.
8. Press the Fan button to choose the intensity of the mist. 1 red light = low, 3 red lights = medium intensity, 5 red lights = high intensity.

CAUTION READ & FOLLOW:

- DO NOT IMMERSE IN WATER
- DO NOT OVERFILL
- DO NOT PLACE IN DISHWASHER
- DO NOT USE CLEANING AGENTS
- DO NOT USE WITH WET HANDS
- FOR INDOOR USE ONLY
- KEEP AWAY FROM CHILDREN & PETS

CLEANING INSTRUCTIONS:

1. The white "umbrella", just beneath the clear lid, should keep most essential oils from reaching the clear lid, yet occasional cleaning will be required.
2. Clean after each use with soft, cotton cloth & warm water only.
3. Do not use any cleaning agents. This will keep the unit in good working order & will maximize the atomizing rate.

IMPORTANT SAFETY INSTRUCTIONS READ & FOLLOW:

1. Use only the adaptor (power supply & cord) supplied with the unit.
2. Do not overfill above white water line. **Overfilling may damage the unit.**
3. Plug in power supply only after the unit is filled with water.
4. Keep on flat, secure, dry surface.
5. Unplug unit from power supply before moving. Unplug when not in use.
6. Do not operate with wet hands.
7. If problem occurs, shut off & unplug unit. Do not attempt to disassemble unit. Repairs should only be done by qualified service centers.

AUTOMATIC SHUT OFF FEATURES:

Unit automatically stops if **water level is too low**. Unit continuously works for **2 hours & stops** automatically. **Low:** Unit disperses for 5 seconds & rests for 40 seconds. **Medium:** Unit disperses for 15 seconds & rests for 50 seconds. **High:** Unit disperses for 30 minutes & rests for 15 minutes.

TROUBLE SHOOTING:

Unit is on yet it does not operate: Check power supply. Be sure power cord is secure in the unit & the outlet. Be sure water level is high enough. Auto shut off occurs when water level is low.
No dispersal or less than usual: Be sure water level is correct & the lid is secure. Check if water level sensor is jammed (the smaller of the 2 projections inside the water tank). Check if transducer is clean (the whole in the center of the water tank). Restart the unit.